HOW TO BUILD AN OUTDOOR CAT SHELTER

SUPPLIES

· 27 gallon plastic storage bin

· Bubble insulation

· Gorilla tape

· Adhesive spray

· Wheat straw

TOOLS

· Ruler to measure insulation and shelter opening

· Scissors or box cutter to cut insulation

· Jab saw or Dremel tool to cut shelter opening

INSTRUCTIONS

1. Measure and mark a 5 inch square at least 3 inches from the bottom of the plastic storage bin. A 5 inch square allows cats to pass through but isn't large enough for wildlife to get in.

2. Cut out the square with a jab saw or Dremel tool. Cover the edges with Gorilla tape.

3. Measure the bin's inside panels. Allow for a couple of inches around each panel for the gorilla tape to secure the insulation to the side.

4. Cut the insulation into the measured panels. Spray one side of the insulation with the adhesive spray. Place the insulation in the inside of the bin. Secure panels to the inside with the gorilla tape. Gorilla tape around the edges of the insulation works best.

5. Fill the bin with a generous layer of wheat straw.

6. Turn the bin over so the top is on the bottom.

7. You have completed making an outdoor cat shelter!